

Installation instructions for Tonti relay solution

For fitment to models that mount the coils behind the side cover.

1. Route the wiring such that the bank of four relays is positioned behind the battery. The sheathing should be routed toward the front of the motorcycle.
 - a. The sheath containing five wires (two green, two brown, one black) should be routed to the headlight bucket.
 - b. The sheath containing two wires (one brown, one black) should be routed under the tank near the horn.
 - c. The sheath containing two wires (both white) should be routed to the coils.
2. Connect all black wires with ring terminals to ground.
 - a. In the rear of the battery tray area, the three black wires should be grounded to one of the bolts that secures the rear fender to the frame.
 - b. In the front of the battery tray area, the single black wire should be grounded to the battery negative terminal.
 - c. Near the horns, the single black wire should be grounded to an existing frame grounding point.
3. Coil
 - a. Identify the existing white wire in the main harness that connects to the positive terminal of one of the coils. Disconnect that wire from the coil and plug it into the white wire with the male spade terminal.
 - b. Connect the other white wire back to the coil positive terminal.
4. Horn
 - a. Disconnect the existing wires to the horn.
 - b. Identify the black wire amongst the wires disconnected from the horn. Plug it into the black wire with the male spade terminal.
 - c. Connect the provided brown and black wiring to the horns.
5. Headlight High Beam
 - a. The brown wire with the male spade terminal must be connected to the brown wire that was connected to the original headlight.
 - b. Connect the brown wire into the headlight – in the space left by the removal of the above brown wire.
6. Headlight Low Beam
 - a. The green wire with the male spade terminal must be connected to the green wire that was connected to the original headlight.
 - b. Connect the green wire into the headlight – in the space left by the removal of the above green wire.
7. Headlight Ground
 - a. Unplug the black wire connected to the original headlight. This wire is will not be plugged back in to anything.

- b. Connect the black wire into the headlight – in the space left by the removal of the above black wire.
8. Connect all red wires with ring terminals to the battery positive terminal.

Notes

1. I chose to use the same colors for the same functions as Moto Guzzi.
 - a. Horn = Brown
 - b. Coil = White
 - c. Headlight high beam = Brown
 - d. Headlight low beam = Green
2. From left to right, the bank of relays is organized in the following order.
 - a. Horn
 - b. Coil
 - c. Headlight high beam
 - d. Headlight low beam
3. The relays simply plug in to each receptacle. You may remove them to mount the relay or to replace them, should the need ever arise. You may need to wiggle them a bit as you remove them.
4. The relays are standard automotive micro relays. Replacements may be purchased directly from me or from any auto parts store.
 - a. I chose to fit 5 pin relays, but I do not use terminal 87a. A 4 pin replacement relay would work just fine.
 - b. I chose 20/35 amp relays. The 20 amp circuit covers terminal 87a (which I do not use). Hence, 35 amp is the sizing I chose for all circuits. This is way more than ample for the devices in use.