

Installing conical seals for clutch push rod

Note direction of seal installation

- Not drawn to scale -

