



- KEY**
- 01 MULTIPLE CONNECTORS
 - 02 START-UP RELAY
 - 03 START-UP MAINTENANCE RELAY
 - 04 CLUTCH SWITCH
 - 05 RIGHT LIGHT SWITCH
 - 06 LIGHT LOGIC RELAY
 - 07 GPS COUPLING
 - 08 HORN
 - 09 LEFT LIGHT SWITCH
 - 10 AIR TEMPERATURE SENSOR
 - 11 INSTRUMENT PANEL DIAGNOSIS
 - 12 INSTRUMENT PANEL DIAGNOSIS
 - 13 KEY SWITCH
 - 14 IMMOBILIZER AERIAL
 - 15 REAR RIGHT TURN INDICATOR
 - 16 REAR LIGHT ASSEMBLY
 - 17 LEFT RIGHT TURN INDICATOR
 - 18 LICENSE PLATE LIGHT BULB
 - 19 REAR STOP SWITCH
 - 20 FRONT STOP SWITCH
 - 21 ECU DIAGNOSIS
 - 22 AUXILIARY FUSES
 - 23 MAIN FUSES
 - 24 STARTER MOTOR
 - 25 BATTERY
 - 26
 - 27 GENERATOR
 - 28 MAIN INJECTION RELAY
 - 29 SECONDARY INJECTION RELAY
 - 30 OIL PRESSURE SENSOR
 - 31 NEUTRAL SENSOR
 - 32 LAMBDA PROBE
 - 33 SIDE STAND SWITCH
 - 34 FUEL LEVEL SENSOR
 - 35 FUEL PUMP
 - 36 INTAKE AIR TEMPERATURE SENSOR
 - 37 ENGINE TEMPERATURE SENSOR
 - 38 IDLE MOTOR
 - 39 THROTTLE POSITION SENSOR
 - 40
 - 41 RIGHT CYLINDER OUTER SPARK PLUG
 - 42
 - 43 LEFT CYLINDER OUTER SPARK PLUG
 - 44 RIGHT CYLINDER COIL
 - 45 LEFT CYLINDER COIL
 - 46 RIGHT CYLINDER INJECTOR
 - 47 LEFT CYLINDER INJECTOR
 - 48 VEHICLE SPEED SENSOR
 - 49 FALL SENSOR
 - 50 PICK UP
 - 51 PICK UP CABLE SHIELDING
 - 52 ECU
 - 53 LEFT RIGHT TURN INDICATOR
 - 54 TAIL LIGHT BULB
 - 55 LOW-BEAM/HIGH-BEAM BULB
 - 56 HEAD LIGHT ASSEMBLY
 - 57 FRONT RIGHT TURN INDICATOR

- COLOUR KEY**
- Ar Orange
 - Az Sky blue
 - B Blue
 - Bi White
 - G Yellow
 - Gr Grey
 - M Brown
 - N Black
 - R Red
 - Ro Pink
 - V Green
 - Vi Purple

- DIAGRAM COLOURS - KEY**
- POWER SUPPLY
 - GROUND
 - ENABLING/ SIGNAL
 - ENABLING/ SIGNAL

- ECU CONNECTORS - KEY**
- A Brown
 - B Blue

Griso 1200 8V

